NYU Langone

4.0

would be responsible for compliance with all additional regulatory requirements, including training and medical surveillance.

5.5

- following departmental procedures for minimizing lead exposures during routine work
- requesting a lead investigation prior to any non-routine work that could impact lead-containing building materials
- notifying supervisors of potential lead exposures or other pertinent problems

5.8 who have the potential to disturb lead-containing building materials are responsible for:

- complying with the relevant OSHA standard
- complying with NYULHNYUf0 Tc 0 Tw a2 Tc 0 Tw 16.000 0 0 16.000 [illegible]

- involving lead shielding
- where it is reasonable to anticipate the disturbance of lead-containing building materials

ƒ All surveys shall be conducted by EPA certified inspectors.

6.3

ƒ Employees shall incorporate appropriate measures to control lead-containing dust, debris, fume, and waste during routine in-house operations and maintenance activities. NYU Langone's Standard Safety Precautions for In-house Operations and Maintenance Activities (see Safety Policy 145: Interim Life Safety Program) incorporates appropriate controls for many common building maintenance activities involving presumed LCP, as long as the paint is in good condition. For example, the standard safety precautions are generally adequate for activities such as opening wall cavities, and preparing interior walls, ceilings, doors, door frames, windows, window frames and similar surfaces for painting.

ƒ Prior to initiating non-routine work that will disturb lead-containing building materials, personnel shall submit to EH&S for approval a HASP outlining proposed work practices.

ƒ Workers performing lead abatement, or renovation, ee1tvru, e2 (t10 ( )]TJ-0. -0.002 Tw [w)4 (

- When engineering and administrative controls are not sufficient to reduce worker exposure below OSHA's PEL, controls shall be supplemented by use of respiratory protection. Workers shall use respirators in accordance with Safety Policy 109: Respiratory Protection.

- Workers shall use other PPE (e.g., disposable full body suits with hoods and shoes; goggles; gloves) as needed, consistent with Safety Policy 119: Personal Protective Equipment.

6.4

-

If employees must perform non-routine work that could disturb lead-containing building materials, their manager shall ,

Safety Policy Manual

- Managers and PMs shall provide relevant information (i.e. location, types of waste, on-site contact person name and number) as early as possible, at least one week prior to scheduled work.
- Contractors shall manage lead-containing waste as per Safety Policy 108a: Hazardous Waste from Contractors.
- EH&S or NYULH-LI Hospitality Services, as applicable, shall coordinate:
  - recycling of metals coated with LCPLI -

Policy:

The following are sample specifications for cleanup of lead-containing paint or LCP (e.g. when there is a noteworthy amount of peeling paint). Contractors shall conduct cleanup in a way that limits the potential for exposure to workers and building occupants in accordance with NYULH requirements and the OSHA standard for Lead in Construction (29 CFR 1926.62).

Prior to the start of the work, the Project Manager or other responsible party shall coordinate:

- Access to areas with LCP scheduled for cleanup.
- MEP disconnects.

The contractor shall ensure:

- Their company has a written lead control program, which includes maintaining records.
- Workers have appropriate lead training.
- The work site is separated from adjacent spaces with appropriate barriers (e.g. plastic sheeting, hard barrier), which includes sealing HVAC registers and openings.
- Workers pre-clean the work area using HEPA-vacuums and/or wet methods.
- The site is under negative pressure throughout the duration of the cleanup.
- Workers have access to handwashing facilities for the duration of the work.
- They conduct an exposure assessment as required by OSHA.
- Workers use only HEPA-equipped tools (including vacuums) and wet methods (e.g. water mist sprayer).
- Pre-filters on HEPA-filtered equipment are changed frequently.
- Workers clean site frequently to ensure there is no dust mitigation to adjacent areas..
- Following LCP removal/cleanup, workers conduct a final cleanup (e.g. using HEPA vacuum, wiping down surfaces with a neutralizing agent/detergent such as Ledizolv) to ensure all dust and debris are removed from surfaces.
- Appropriate methods are used to prevent additional peeling, where applicable (e.g. painting surfaces with a latex primer).
- The work area is secured/locked during off hours.

- Cleanup materials (e.g. tools, used PPE, waste) are not stored outside of the work area (e.g. adjacent corridors, offices, stairwells).

- Paint waste is collected for TCLP testing. PPE and containment materials may need to be collected separately. Waste col

Trained and certified lead-abatement contractors and workers shall be used to perform the project. Each supervisor and worker assigned to the project must have EPA certification available at the project site. Contractors must possess an EPA Contractor Certification Number.

a) The workers who remove paint shall be trai

in a continuous-flow mode; or full facepiece self-contained breathing apparatus (SCBA) operated in demand mode.

iv. Air lead levels between 2500 µg/m^3 and 50,000 µg/m^3: Half-mask supplied air (protection 1,000X) respirator operated in pressure-demand or other positive pressure mode.

v. Air lead levels between 50,000 µg/m^3 and 100,000 µg/m^3: Full facepiece supplied air (protection 2,000X) respirator operated in pressure demand or other positive pressure mode (e.g., type CE abrasive blasting respirators operated in a positive pressure mode).

vi. Greater than 100,000 µg/m^3, unknown concentration or firefighting: Full facepiece SCBA operated in pressure-demand or other positive pressure mode (protection over 2000X).

d) Only approved National Institute of Occupational Safety and Health (NIOSH) respirators shall be used. Respirators shall be properly fitted for all persons working at the site.

e) The manufacturer's instructions shall be followed for maintenance, proper fit, use of appropriate cartridges, cleaning, repair, and replacement of

- dry-sanding
- open abrasive blasting
- uncontained hydro-bl

i) HEPA vacuum the exterior of all waste containers prior to removing the waste containers from the work site or area and wet wipe the containers to ensure that there is no residual contamination. Containers that have been cleaned shall be moved out of the work site or area into a designated storage area.

j) Carefully